

## Installation Information

Item #P0007BE

Turn & Lift - Waste & Overflow Drain Assembly

Warranted only if installed by a qualified licensed plumber. Use Teflon tape on all threaded connections.

1. Assemble parts as shown before installing to get the accurate length needed for the overflow and drain tubes.
2. The rough-in for the drain hole on the floor is a plumb line from the center of the roll rim on the tub to the floor.
3. Rough-in  $1\frac{1}{2}$ " male IPS with  $\frac{1}{2}$ " above the finished floor.
4. All tubing is  $1\frac{3}{8}$ ", replicating the original size of these drains.
5. Use the enclosed  $1\frac{3}{8}$ " X  $1\frac{1}{2}$ " reducing washer to connect this set with a  $1\frac{1}{2}$ " drain.

