

Strom Plumbing

BY

Sign of  the Crab

Ph: (916) 638-2722 / Fax: (916) 638-2725

INSTALLATION INFORMATION

ITEM #P0091

“L” Shape Shower Surround

Parts Included

Tub Surround:

1 pair P0071 Wall Brackets
1 - P0069 L Shaped End Rod
1- GB0283 6' Shower Rod

Ceiling Brace:

1 - GB0282 Ceiling Escutcheon
1 - P0070 Ring Support
1 - P0095-36" Ceiling Brace

ASSEMBLE PIECES ON FLOOR PRIOR TO INSTALLING FOR ACCURATE MEASUREMENTS.

1. Measure the total length needed for the shower rods according to the total size of the tub surround.
2. Lay out pieces on the floor to determine if either of the 6' rods will need to be cut (according to the length of your tub) or if the L shaped rod will need to be shorter (according to the width of the tub) prior to assembly.
3. Slide a P0070 ring support on the 6' rod where you want to install the ceiling brace. *This will restrict the flow of your shower curtain.*
4. *Insert the 6' rod into the flared end of the L shaped rod. Determine if this rod length will need to be cut to fit.*
5. Make all cuts and size adjustments to the tub surround parts prior to installing on the wall.
6. Once the surround size has been determined and loosely assembled, tighten all set screws.
7. Mount the P0071 wall brackets on the wall according to your length measurement.
8. Insert the P0069 end rod into the P0071 bracket.
9. Determine where to mount the GB0282 ceiling escutcheon for the 36' ceiling brace and mount accordingly. (This brace length may be cut down to fit if 36" is not needed) *This brace can be placed anywhere along the 6 foot rod. It will restrict the flow of your shower curtain depending on where it is installed.*
10. Re-check all set screws to make sure they are tight.

