

Strom Plumbing



Ph: (916) 638-2722 / Fax: (916) 638-2725

Installation Information

Item #P0959 & P0959EXT Oval Enclosure

This unit can be installed with or without a shower riser. If using without a riser, then the wall support is required. If installed without a wall support, the warranty is voided.

If using with a riser, this unit includes clamps to fit a 5/8" OD or a 3/4" OD riser.

1. Slide the two halves of the enclosure together to form an oval.
2. Install the ceiling clamps onto the oval at both ends.
Note: The ceiling braces will restrict the flow of your shower curtain.
3. Install the wall clamp onto the oval.
4. After measuring the proper length needed of the ceiling rods and the wall support rod, you may cut these to the desired length. CUT THE NON-THREADED END ONLY AND DO NOT INCLUDE THE THREADED PORTION IN YOUR MEASUREMENT.
5. Install the escutcheons onto the wall & ceiling in their proper positions.
6. **NOTE: TWO PEOPLE ARE NEEDED FOR THE REMAINING STEPS:**
Very carefully screw the ceiling braces firmly into the ceiling clamps. Do not flex the joints. Insert the ceiling braces into the ceiling escutcheons and tighten the screws. There must be someone on both ends to reduce flex.
7. Very carefully screw the wall brace firmly into the wall clamp. Install the wall brace into the wall escutcheon and tighten the screw.

